

TOOLS NEEDED: Two $\frac{7}{16}$ " Wrenches or adjust. Wrenches
 $\frac{1}{8}$ " Allen Wrench (included)

PARTS INCLUDED: Back rest
Seat
2 Arm Assemblies
2 Glider Assemblies
2 Glider Cross Braces
2 Glider Mounting Braces

HARDWARE: 8 - $2\frac{1}{2}$ " Joint Connector Bolts
8 - $2\frac{3}{4}$ " Joint Connector Screws
12-Washers
4 - $1\frac{1}{2}$ " Hexhead Bolts
4 - 2" Hexhead Bolts
4 - 9" Glider Bearing Arms
12 Locking Nuts



✂ ASSEMBLY TIP: For ease of assembly, finger-tighten all fasteners first. Tighten securely after all parts are aligned. Do not over tighten. Holes are drilled to easily accept hardware. However, because of finish the holes may be tighter than normal. Lightly tapping the hardware with a hammer will help with the assembly. Using some soap on the screws will make the job a little easier.



1. Matching pre-drilled holes, attach the seat to one of the arm assemblies using (2) $2\frac{1}{2}$ " connector bolts and the $\frac{1}{8}$ " Allen Wrench. The notches in the seat should face forward. Finger-tighten only until you have completed step #2. Attach the other arm assembly the same way.



2. Matching pre-drilled holes, carefully slide the backrest between the two arm assemblies. This is easy to do if the seat assembly is not securely tightened. Use (2) $2\frac{3}{4}$ " joint connector screws on each arm. Securely tighten bolts and screws – **DO NOT OVERTIGHTEN.**



3. Attach the glider cross braces to the glider assemblies, using (2) $2\frac{3}{4}$ " Joint Connector Screws through pre-drilled holes on each brace.



4. Attach the (4) 9" glider bearing arms to the outside of the glider base using (4) 2" hexhead bolts, washers and locking nuts. Insert bolts from the outside with the washers and nuts on the inside. Glider bearing arms should be angled outward when properly attached.



5. Attach glider mounting brace to gliders using (2) 1 1/2" hexhead bolts, washers and locking nuts on each side with the nuts to the outside.

6. Position the bench assembly over the base assembly (the longer curve of the base should be towards the back) and attach glider mounting braces to arms using (2) 2 1/2" Joint Connector Bolts, washers and nuts on each arm. Bolt heads should be on the outside of the arm. When properly assembled, the glider bearing arms will hang slightly towards each other. Securely tighten all nuts and bolts.

CARE INSTRUCTIONS

Your new furniture requires very little maintenance. It may be washed with a mild detergent and water to remove surface dust and dirt. After prolonged exposure to the elements you may want to refinish it. We recommend lightly sanding it prior to refinishing, then use a cloth to remove the dust, refinish with a high quality exterior finish. It may be necessary at times to tighten the bolts and screws. It is normal for bolts to loosen somewhat in wood furniture. In northern climates, we recommend that the furniture be stored inside during the winter months.

LIMITED WARRANTY

This product is warranted only against defects in materials and workmanship for one year following the date of purchase. This limited warranty is in lieu of all other warranties, expressed or implied, and no one is authorized to assume for the company any other liability in connection with their sale of this product. This warranty gives you specific rights and you may also have other rights, which vary, from state to state.

For questions or replacement parts, please call our office.

www.prairieleisure.com